

SYS

Nexus Client ~~X~~ Computer

NexusClientSys

~~X~~ Video Controller

~~X~~ Podium Control panel

Input Selector

Output Selector

Jack^{*}

~~X~~ Podium Computer

Inter net

Data ^{*} Propagator

~~X~~ Proj^{*} Screen Motor

~~X~~ Video Screen

Loud Speaker

KB M S TP

Projection Screen

On B

Off B

Up B

Down B

Sound Source

Video Source

~~X~~ Laptop
~~X~~ KB M S TP

Lecturer

Apple^{*} Nexus Server

Listener

Env

